



# SEA<sup>®</sup>

Sistemi Elettronici  
di Apertura Porte e Cancelli  
International registered trademark n. 804888



**Italiano**

**English**

**Français**

**Español**

**Deutsch**

# USER 2 - 24V

23024015/16


**APPARECCHIATURA ELETTRONICA 24Vdc PER CANCELLI AD ANTE BATTENTI**

**ELECTRONIC CONTROL UNIT FOR SWING OPERATORS 24 V D.C.**

**ARMOIRE ELECTRONIQUE 24 V dc POUR PORTAILS A BATTANTS**

**TARJETA ELECTRONICA 24Vdc PARA CANCELA ABATIBLES**

**ELEKTRONISCHE 24Vdc STEUERUNG FÜR SCHWINGTORE**



SEA s.r.l.

Zona Ind.le S. Atto - 64020 S. Nicolò a Tordino (TE)

Tel. 0861.588341 - Fax 0861.588344










[www.seateam.com](http://www.seateam.com)

e-mail: [seacom@seateam.com](mailto:seacom@seateam.com)



# **CONNESSIONI / CONNECTIONS / CONNEXIONS**


## **CONEXIONES / VERBINDUNGEN**





**CONNESSIONI / CONNECTIONS / CONNEXIONS**

**CONEXIONES / VERBINDUNGEN**






# **INDICE**

|   |    |
|---|----|
| COMPONENTS' DESCRIPTION .....                                       | 21 |
| GENERAL INFORMATION .....   | 22 |
| START, STOP, PEDESTRIAN START, ANTENNA, PHOTOCCELL CONNECTIONS..... | 23 |
| ENCODER, LIMIT SWITCH, ELECTRIC LOCK, WARNING LAMP, EDGE.....       | 24 |
| POWER SUPPLY AND MOTORS ARM - ALPHA - BETA CONNECTIONS.....         | 25 |
| SELFLEARNING WORKING TIMES .....                                    | 26 |
| SETTINGS' SELECTION .....   | 27 |
| EXTERNAL RECEIVER CONNECTION AND RADIO TRANSMITTER LEARNING .....   | 28 |
| FUNCTIONING LOGICS.....   | 29 |
| BUS SYSTEM DESCRIPTION .....  | 29 |
| DISPLAY PARAMETERS REGULATION.....                                  | 30 |
| CONNECTION OF BATTERIES .....                                       | 32 |
| ALARMS AND MAINTENANCE DESCRIPTION .....                            | 32 |
| TROUBLE SHOOTING .....  | 33 |
| INSTRUCTIONS AND GUARANTEE.....                                     | 34 |
| TERMS OF SALE.....  | 35 |



# **DESCRIPTION OF THE COMPONENTS**



**LED1** = Fuse breaking signal  
**LED2** = Start  
**LED3** = Photocell  
**LED4** = Limit switch opening M1  
**LED5** = Limit switch closing M1  
**LED6** = Pedestrian Start  
**LED7** = Stop  
**LED8** = Battery  
**LED9** = 24Vdc Power supply  
**LED10** = Using modality  
**LED11** = Limit switch opening M2  
**LED12** = Time of pause  
**LED13** = Limit switch closing M2  
**LED14** = Safety edge  
**LED15** = TX Programming  
**LED16** = Leaf delay adjustment  
**LED17** = Functioning logics  
**LED18** = BUS Indicator  
**LED19** = Function indicator  
**LED20** = Function indicator  
**LED21** = Function indicator  
**LED22** = Motors' speed adjustment  
**SET** = Setting  
**MENU** = Selection

**M1** = Motor 1 power supply  
**M3** = Battery card connection  
**M4** = Motor 2 power supply  
**M5** = 24Vdc exit  
**M6** = 24V 15W Warning lamp  
**M7** = Start  
**M8** = Electric lock exit  
**M9** = Photocell connection  
**M10** = Pedestrian start  
**M11** = Encoder / Limit switch M1  
**M12** = Stop  
**M13** = Security edge  
**M14** = Encoder / Limit switch M2  
**M15** = BUS accessories connection  
**M16** = Antenna  
**CMD** = Display module connection  
**CMR** = Receiver module connection  
**CALM** = 24Vdc power supply connection



## GENERAL INFORMATION

### GENERAL CHARACTERISTICS

The USER 2 24V control unit has been designed to manage one or two low voltage swing gate operators with or without electronic limit switches.

It is very small and besides the possibility to adjust the: motor speed, amperometric sensitivity for the anti squeezing, leaf delay in closing, pausing time, it is also possible to manage a display, through which it is possible to control numerous functions of management and the maintenance of the control unit. The most important novelty however concerns the presence of a BUS connector with two threads, through which it is possible to connect the accessories as photocells, flashing lamp, key switch and so on,... bringing only two cables to the control unit. The self-learning of working time can be done automatically.

### TECHNICAL CHARACTERISTICS

|  |   |
|--|---|
| <b>Control unit power supply</b>             | 24 Vdc  |
| <b>Absorbt power</b>                         | 10 W  |
| <b>Max. motor charge</b>                     | 90 W x 2  |
| <b>Max. accessories charge</b>               | 24Vdc 250mA   |
| <b>Max. Flash light charge</b>               | 24Vdc 15W max.  |
| <b>Environment temperature</b>               | -20°C +50°C   |
| <b>Protection fuse (24V accessories)</b>     | 1 (250mA)   |
| <b>Function logic</b>                        | Automatic / Manual / Security / Semiautom.  |
| <b>Opening/closing time</b>                  | In selflearning in programming phase  |
| <b>Time of pause</b>                         | Adjustable with push button   |
| <b>Thrust</b>                                | Adjustable with display   |
| <b>Slow down</b>                             | Adjustable with display   |
| <b>Entries on connecting terminal</b>        | Battery power supply / Total opening / Pedestrian opening adjustable / Edge/ Stop / Limit switch opening and closing / Encoder/ BUS accessories |
| <b>Exit on connecting terminal</b>           | Power supply accessories 24Vdc / Motors 24Vdc / Flashing lamp 24Vdc / Electric lock 12Vdc /   |
| <b>Board dimensions</b>                      | 156 x 100 mm  |
| <b>Characteristics optional batteries</b>    | 24V Pb 2Ah min.   |
| <b>Characteristics of external enclosure</b> | 305 x 225 x 125 mm - Ip55   |

### ARRANGEMENTS

**For the security of persons it is important to follow with attention all the advises and instructions in this manual. A wrong installation or a wrong use of the product can cause sever dammagages to persons.**

Make sure that the installation has an adequate differential switch as prescribed by the law in force and local isolation at the control panel.

For the installation of the electric cables use adequate rigid and/or flexible ducts.

Always separate the connection cables of low voltage accesssoires from those of 230V~ power supply. To avoid any interference use separate casings.

**Max. Length of the power supply cable between control unit and motors is 10m, using cables with 2,5 mm<sup>2</sup> section.**



# SEA®

Sistemi Elettronici  
di Apertura Porte e Cancelli  
International registered trademark n. 804888

## English

## USER 2 - 24V

# START - STOP - PEDESTRIAN START - ANTENNA - PHOTOCELL

### Photocell 1 Connection



When the ray of the photocell is crossed, and the automation is in phase of closing it reverses its movement. Through display it is possible to activate the photocell in opening, if activated it causes the interruption of the movement as long as it is busy, for then continuing the opening as soon as it is released.

**Note: If the photocell is not connected, put a jumper between the clamps 1 and 2 of (M9).**

+ = 24Vdc    - = 0Vdc    C = Connection


Com = Common

The photocell is also usable in connection with BUS photocells.




### ANTENNA

Connect the antenna as in the picture.



### M10



### PEDESTRIAN START (N.O.)

To obtain a partial opening (only one leaf opening) connect the key-button wires as in the picture. It is possible to connect other command devices (push button board, radio receiver, keypad).


From the display it is possible to adjust the pedestrian opening space: 30%, 50%, 100%.

Note1: The contact for partial opening is a N.O. Contact (Normally open)

Note2: Partial opening will always operate the **M1** motor.

Note3: In manual logic it is necessary to keep pressed the Start ped for the reclosing of the leaf.

### M12




### STOP (N.C.)

The pressure on this button immediately stops the motors in any condition /position. A start command is needed to re-start movement.

After a stop the motors always re-start in closing.

Notice: If stop button is not used make a jumper between terminals n° 1 and 2 of M12.

### M7



### START (N.O.)

An impulse given to this contact opens and closes the automation depending on logic selected. It can be given by a key switch, a keypad, etc.

To connect the other devices refer to the related instructions leaflets. (ie. loop detectors and proximity switches)

Note1: In manual logic it is necessary to keep pressed the Start for the opening of the leaf.



# ENCODER - LIMIT SWITCH

## Encoder (Function not activated)


The encoder is a device that allows to reveal possible obstacles during the opening and the closing of the gate.

When this device intervenes in opening it causes the inversion of the movement for around a second, if it intervenes in closing it causes the total reopening.

**Note 1:** Such function is active through an amperometric sensor on the control board.

**Nota2:** The amperometric sensitivity is adjustable through the Palmuser modifying the motor torque parameter for every single leaf. With torque 100% the gate reverses after 5 seconds.

**Attention:** after every intervention of the ammeter sensor it is necessary to give a start impulse to restore the movement.



## PHOTOCELLS

If not connected they don't have to be bridged.

For the limit switch function the presence of the limit switches in both closing and opening is necessary. In case of single leaves it is not necessary to bridge the limit switch of the motor 2.

Com = Common  
C = Contact

From display it is possible to activate the function anti-intrusion. Such function is tied up to the presence of at least one limit switch, that if freed, forces the motor to re-close.


# SECURITY EDGE

# ELECTRIC LOCK AND WARNING LAMP

## Electric lock exit

An electric lock of 12Vdc 15W max can be connected.

The electric lock activates at every opening cycle for about 1,5 sec.



It is possible to connect an active safety edge on the terminal M13. If this device is pressed it opens the contact causing a partial inversion of the movement both in opening and in closing. If not used bridge the contacts 1 and 2 of M13. Note: contact N.C.

**M13**

Safety edge

## Flashing Lamp 24V 15W (Warning lamp)

The flashing lamp gives warning that the gate is moving.






To connect, wire the flashing lamp as in the picture. It is possible to activate a pre-flashing of 3 seconds before activating the automation, setting pre-flashing on ON, through the display module. Furthermore, it is possible to verify some alarm signals from the warning lamp. See pag.32.

**Attention :** Through the PALM USER it is possible to transform this exit into warning lamp. In such case all alarm signalisations rest on the flashing lamp as long as they are active.

With open gate in In half automatic logic it remains switched on with fixed light.




**POWER SUPPLY - MOTORS ARM-ALPHA-BETA**



**Power input**

Input for the connection of the electric power.  
P = PHASE - LIVE  
N = NEUTRAL

**NOTICE:** for the connection to the electric power see the law in force.







# SELFLEARNING WITH DEFAULT PARAMETERS

To learn the times with the default settings, it is sufficient to press the Menu button once and to hold pressed the SET button until the departure of the motors in closing.


The settings of **DEFAULT** are: SEMIAUTOMATIC LOGIC, DOUBLE LEAF ENCODER OFF, SPEED 75%, LEAF DELAY 3 SEC., PAUSE 2 SEC., ANTI-SQUEEZING 75%, SLOWDOWN SPEED 30%, LEARNING SPEED 50%, ACCELERATION 70%, DECELERATION 30%, LEAF STROKE OFF, ANTI-INTRUSION OFF, SELFTEST OFF, PEDESTRIAN 100%, PHOTO OPENING OFF, MAX CYCLES 10000.

## WORKING TIMES SELF LEARNING

- 1) Make sure that each accessory (photocells, push buttons, and so on) works properly and adjust the leaf delay if necessary.
  - 2) If necessary adjust the self-learning speed through the palm user.
  - 3) Disconnect the power supply (Fig. 1), release the motors (Fig. 2-3) and put the leaves manually near the stop in closing (Fig. 4). Reset the mechanical lock (Fig. 5-6)
  - 4) Connect the control board to the power supply (Fig.7).
  - 5) Press the selection button "MENU" so to switch on LED10
  - 6) Press the button "SET" until the led of the color corresponding to the type of application (single leaf, double leaf, Encoder ON, Encoder OFF) switches on.
  - 7) Hold pressed the button "SET" until the motors start in closing and then release the button.
  - 8) Both leaves will start the closing with reduced speed (Fig.4).
  - 9) At the attainment of the stops they will automatically execute an opening cycle with reduced speed (Fig.8). At the attainment of the stop in opening they will automatically perform a closing cycle.
  - 10) Wait for the closing end of the leaf (Fig.9).
- The self-learning is done.



- A) Select LED 10 of the self-learning through the MENU button, with LED 10 turned on press button SET to choose the function modality:
- led L20 yellow = double leaf Encoder OFF
  - led L19 and 20 green and yellow = double leaf Encoder ON
  - led L21 red ON = single leaf Encoder OFF
  - led L19 and 21 green and red = single leaf Encoder ON
- B) Once the functioning modality has been chosen hold pressed SET up to the departure of the motors in closing and then release the button.






## **SELECTION OF THE SETTINGS**

The adjustments of the control unit are executed through the buttons "MENU" and "SET".

Pressing the "MENU" button you select the Leds corresponding to the various functions to be set, pressing the "SET" button you select the leds corresponding to the desired values inside every single function.



Selecting with the button "MENU" the LED 12 turns on at the pausing time regulation, with LED 12 turned on, hold pressed the selected button "SET" for the desired time of pause. In function of the colour that the leds 19, 20 and 21 will assume it will be possible to have an order of the length of the set time of pause. If the button is released and then pressed again the time of pause will be annulled.

- Led L19 green turned on Time of pause <15 sec.
- Led L20 yellow turned on Time of pause <45 sec.
- Led L21 red turned on Time of break >45 sec. Up to 2 mins.

Selecting with the button "MENU" LED 16 turns on at the adjustment of the opening of the leaf delay, with LED 16 turned on press the button "SET" till to select the desired leaf delay, observing the colour of the leds 19, 20 and 21.

- Led L19 green turned on leaf delay OFF
- Led L20 yellow turned on leaf delay <4 sec.
- Led L21 red turned on leaf delay >4 sec. Up to 7 sec

Selecting with the button "MENU" LED 17 turns on at the choice of the functioning logic, with LED 17 turned on press the button "SET" till to select the desired logic, observing the colours of the Leds 19, 20 and 21.

- Led L19 green turned on manual logic
- Led L20 yellow turned on automatic logic
- Led L21 red turned on security logic
- Led L19 and L20 green and yellow turned on semi-automatic logic.

Selecting with the button "MENU" LED 22 turns on at the choice of the motors' speed, with LED 22 turned on press the button "SET" till to select the desired speed, observing the colours of the leds 19, 20 and 21.

- Led L19 green turned on slow speed
- Led L20 yellow turned on middle speed
- Led L21 red turned on high speed
- Hold pressed "SET" for more then 5 seconds to annul the executed number of cycles


Selecting with the button "MENU" the LED 10 and LED 12 with alternate flash you enter into the motor torque adjustment. With LED 10 and LED 12 flashing alternatively keep pressed the button "SET" while selecting the desired torque observing the color of the LEDs 19, 20, 21.

- Led L19 green turned on, torque = 50%
- Led L20 yellow turned on, torque = 75%
- Led L21 red turned on, torque = 90%
- Led L19, L20 and L21 turned on, troque = 100%

After 30 seconds without having pressed any button, the parameters' adjustment function will be automatically left. If the control unit turns on when holding pressed the buttons "MENU" and "SET" contemporarily, the control unit will be started with the parameter of DEFAULT (see preceding page).




## EXTERNAL RECEIVER



### Connection of a radio receiver

For the connection of the receiver refer to the relative instructions manual.




## RADIO TRANSMITTER SELF LEARNING

### WITH RECEIVER ON BOARD OF CONTROL UNIT

**WARNING:** Make the radio transmitters programming before you connect the antenna and insert the receiver into the special CMR connector (if available) with turned off control unit.

1. Press repeatedly the button "MENU" till to select the led 15 (red), at this point press the button "SET" and the led15 will flash together with the led 19 (green) to signal that it waits for a code to be associated to the total opening;
2. Press the desired button of the radio transmitter, the led19 (green) will turn off to signal the memorisation of the data;
3. If it is desired to also associate a command to the pedal (a start), press SET again, the led 20 (yellow) will flash for signalling that it is waiting for a code to be associated to the pedal opening;
4. Press the desired button of the radio transmitter, LED 20 will turn off to signal the memorisation of the data.
5. At this point it is possible to press the desired button of the radio transmitter and the leds 19,20, 21 (green, yellow, red) will show the available memory, led19 (green) shows the occupied memory, less than 50%, led 20 (yellow) shows the occupied memory, more than 50%, led 21 (red) full memory.
6. To delet all memorized codes keep pressed for more than 5 seconds the adjusted button until the leds yellow, red and green will flash contemporarily to confirm the cancellation



### Notes:

- Enter radio transmitters learning only when the working cycle stops and the gate is closed.
- It's possible to memorize up to 800 codes (buttons).
- If all available codes have already been memorized and you try to memorize a further code, the led 21 (red) will flash for signalling the error.
- If the board receives a code which was already associated to another function it will be updated with the new function.



## FUNCTION LOGIC

### **SEMI AUTOMATIC LOGIC**

A start impulse opens the gate. A second impulse during opening stops the movement.

With the gate opened a start impulse is necessary for its re-closing. A start commande during the closing reverses the movement.

### **SECURITY LOGIC**

A start impulse opens the gate. A second impulse during opening reverses the movement. A start impulse during closing reverses the movement. A start commande during pause causes the immediate re-closing.

### **MANUAL LOGIC**

The gate opens when the **Start** push button for opening is pressed and held; releasing it stops the gate. The gate re-closes as long as the button connected to the **pedestrian START** will be pressed; releasing it stops the gate. To execute complete opening and/or closing cycles it is necessary to keep the relative push buttons constantly pressed.

### **AUTOMATIC LOGIC**

A start impulse opens the gate. A second impulse during the opening will not be accepted. An impulse during the pause won't be accepted. An impulse during the closing reverses the movement.

## DESCRIPTION OF THE BUS SYSTEM

The BUS is a connecting system through which it is possible to connect different accessories among which: photocells, key switches, warning lamps, numerical keyboards and key selectors, all in parallel on the same entry and all through two only threads. This system therefore allows to eliminate the two threads of the power supply for the accessories, therefore every accessory will be equipped with only two threads. Every accessory is equipped with a rotating changer, which allows to join the various devices according to a numerical sequence which defines the particular function assigned to that accessory.

### **Photocells BUS addressing**

Rotating Changer on TX and FX on 0 or 1 = photocell active only in opening  
Rotating Changer on TX and FX on 2 or 3 = photocell active only in closing  
Rotating changer on TX and FX on 4 = photocell both in opening and in closing.  
The positions from 6 to 9 are interpreted as active photocells both in closing and in opening.


Note: Two couples of photocells with the same function have to have a different number. For ex. on two couples in closing TX and FX of the first one will have the number 2, TX and FX of the second couple will have the number 3.

### **Initialization BUS**

Connect all the devices in parallel on the clamp M15 or in parallel between them.

At the lighting of the control unit make sure that the LED18 (red) performs some fast flashes, at this point, if the red led remains turned on this means that there is an error on the BUS, signalled from the display or by 8 flashes on the warning lamp, but if the red led will keep on flashing slowly the BUS is perfectly working.

**NOTE: To repeat the search of the peripheral BUS in case of BUS error, press contemporarily the buttons + and - of the display.**





# DISPLAY PARAMETERS ADJUSTMENT

The accessory PALM USER allows to keep under control all the parameters of the control unit and it results essential for the initial setting of some parameters, which are: pre-flashing, photocell self-testing, photocell in opening, anti-intrusion, torque motore1 and 2, deceleration speed, learning speed, acceleration, deceleration, leaf stroke, number of cycles, pedestrian opening.

| Screen 1           |   |
|--------------------|---|
| Cycle              | Semiaut./manual/automatic/security              |
| Double/single leaf | Select double or single leaf                    |
| Encoder            | on/off (function with encoder, not implemented) |
| Time of pause      | [0÷120]s (time of pause in seconds)             |

Shows the working logic adjusted on board of the control unit.

| Screen 2    |   |
|-------------|---|
| Cicli exec. | [0÷2 <sup>32</sup> ] (number of executed cycles)                              |
| Mem. free   | [0÷100]% (percentage of available memory for the learning of remote controls) |
| Learning    | on/off (signalling of the execution of the learning)                          |

| Screen 3     |                                       |
|--------------|---------------------------------------|
| Speed        | [30÷100 ] adjusts the motors' speed   |
| Sl. speed    | [30÷100 ] adjusts the slow down speed |
| Lear. Speed. | [30÷100 ] adjusts the learning speed  |

Adjustment with the buttons + and - of the PALM USER

| Screen 4      |   |
|---------------|---|
| Photocell Tx1 | [OK-NP] (peripheral reveal - not present) |
| Photocell TX2 | [OK-NP] (peripheral reveal - not present) |
| Photocell TX3 | [OK-NP] (peripheral reveal - not present) |
| Photocell TX4 | [OK-NP] (peripheral reveal - not present) |

The screens 4, 5, 6, 7, 8 and 9 show the type of accessory on the BUS.

| Screen 5      |   |
|---------------|---|
| Photocell TX5 | [OK-NP] (peripheral reveal - not present) |
| Photocell RX1 | [OK-NP] (peripheral reveal - not present) |
| Photocell RX2 | [OK-NP] (peripheral reveal - not present) |
| Photocell RX3 | [OK-NP] (peripheral reveal - not present) |

| Screen 6      |   |
|---------------|---|
| Photocell RX4 | [OK-NP] (peripheral reveal - not present)   |
| Photocell RX5 | [OK-NP] (peripheral reveal - not present)   |
| Proximity n°1 | [OK-NP] (peripheral reveal - not present) * |
| Proximity n°2 | [OK-NP] (peripheral reveal - not present) * |



# DISPLAY PARAMETERS ADJUSTMENT

**NOTE:** For the respect of the valid European rules on the safety of the electric gates, it is recommended to not adjust the parameters **torque Max 1** and **torque Max 2** on the value 100%.

| Screen 7           |   |
|--------------------|---|
| Proximity n°3      | [OK-NP] (peripheral reveal - not present) * |
| Pushbutton board   | [OK-NP] (peripheral reveal - not present) * |
| Num. Push b. Board | [OK-NP] (peripheral reveal - not present) * |

| Screen 8         |   |
|------------------|---|
| Interf.Photo     | [OK-NP] (peripheral reveal - not present) * |
| Interf. commands | [OK-NP] (peripheral reveal - not present) * |

| Screen 9      |   |
|---------------|---|
| Flashing lamp | [OK-NP] (peripheral reveal - not present)   |
| Sel. Key      | [OK-NP] (peripheral reveal - not present) * |

| Screen 10      |  |
|----------------|--|
| Accelerat.     | [0÷100]% (inclination of the ramp of acceleration) |
| Decelerat.     | [0÷100]% (inclination of the ramp of acceleration) |
| Leaf delay     | [0÷7] sec (adjusted leaf delay)                    |
| Pedestrian op. | [30,50,100]% (percentage pedestrian opening)       |

It allows to regulate the duration of the acceleration of the motors on the start. If on 100% the gate will immediately depart at the max. adjusted speed.

It allows to regulate the duration of the deceleration of the motors at the end of opening and closing. If on 0% the gate won't effect the phase of deceleration.

It regulates the duration of the leaf delay. Adjustable with the buttons + and - of the PALM USER or on the control unit.

Regulates the pedestrian opening space. Adjustable with the buttons + and - of PALM USER.

| Screen 11        |  |
|------------------|--|
| Torque max1      | [10÷100]% (max. current of the motors)         |
| Torque max2      | [10÷100]% (max. Current of the motors)         |
| Photo in opening | on/off (attivazione fotocellula in apertura)   |
| Leaf storke      | on/off ( leaf stroke to release/lock the lock) |

Allows to regulate and to visualize the sensitivity of the anti-squeezing. With value 100% the gate in presence of obstacle will reverse the movement after 5 seconds.

Activates a leaf stroke at the beginning of opening and at the end of closing

| Screen 12       |  |
|-----------------|--|
| Anti-intrusion  | on/off (in ON it implicates the presence of a contact N.C. on the limit switch that, if freed, forces the motors in closing) |
| Pre- flashing   | on/off (activation of the pre-flashing)  |
| Autotest photo. | On/off (activates autotest photocell)  |
| Max cycle       | 0÷100000 (indicates the number of cycles after which it is necessary to follow up the maintenance)                           |

Activates or disactivates the pre-flashing.

Activates or disactivates the leaf delay.

| Screen 13    |  |
|--------------|--|
| Warning lamp | ON/OFF (while on ON the alarm signalisation will rest on the flashing light until they are eliminated) |



**Note:**

The indications for the peripheral marked with \* are not possible because not implemented. The presence of "Interf. Commands" depends on the adjustment of the changer of the interface I/O.



# CONNECTION OF BATTERIES

**FUNCTION NOT YET AVAILABLE**



Insert two 12V batteries connected in series.

## ALARMS INDICATIONS

The flashing sequence is signalled at every opening and closing of the automation on the warning lamp. The warning lamp will send a flashing every second in opening and two flashings in closing, while it will remain turned on fixed in pause.

| Flashings Number | Kind of alarm        | Flashings Number | Kind of alarm          |
|------------------|----------------------|------------------|------------------------|
| 2                | Photocell            | 6                | Collision on obstacle  |
| 3                | Photocell in opening | 7                | Reached maximum cycles |
| 4                | Safety edge          | 8                | Alarm BUS              |
| 5                | Stop                 | 9                | Motor failure          |

## ALARM SIGNALS

The damages with 2,3, 4 and 5 flashings, refer to normally closed contacts, therefore verify if such are the connections and/or the correct working of the photocells, of the Stop button and/or of the safety edge.

2. The failure with 6 flashes refers to a collision with an obstacle which has been revealed by the ammeter sensor, therefore it is necessary either to replace the motor or to verify the conditions of the connections.

3. Periodically, in relation to the number of manoeuvre and the type of gate, it is recommended to execute, if the gate has modified the attritions and it doesn't work, **the re-programming of the times of learning on the electronic board.**

The damage with 7 flashes refers to the attainment of the established maximum cycles for the maintenance of the control unit, therefore it is necessary to perform the maintenance and to put on zero the number of cycles, according to the following procedure: Through the button SEL select the led 22 of the motors' speed, keep pressed the chosen button for more than 5 seconds.

4. The damage with 8 flashes indicates a generic error on the BUS, this means that there is a short circuit on one of the connected devices to the BUS, and it is necessary to verify the connections and the functionality of the connected devices or the connected devices are not correctly joined between them (see paragraph on the BUS management)

5. The failure with 9 flashes refers to a shortcut on the motor, therefore it is necessary either to replace the motor or to verify the conditions of the connections.

## MAINTENANCE

Periodically, considering the number of working cycles and the kind of gate, it's necessary to proceed, if the gate has changed the frictions and doesn't work, with **learning times reprogramming on the electronic control unit.**



## **TROUBLE SHOOTING**

### **Advises**

**Make sure all Safety LED are turned ON**  
**All not-used N.C. contacts must have jumpers**

| <b>Problem Found</b>                                   | <b>Possibile Cause</b>  | <b>Solution</b>  |
|--|---|--|
| Motor doesn't respond to any START impulse             | <ul style="list-style-type: none"> <li>a.) Jumper missing on one of the N.C. Contacts</li> <li>b.) Burnt fuse</li> </ul>  | <ul style="list-style-type: none"> <li>a.) Check the connections or the jumpers on the connections of the safety edge, of the stop and of the photocell</li> <li>b.) Replace the burned fuse on the control unit led 1 turned on.</li> </ul> |
| Gate doesn't move while the motor is running           | <ul style="list-style-type: none"> <li>a.) The motor is in the released position</li> <li>b.) The electronic clutch are not set</li> <li>c.) There is an obstacle</li> </ul>  | <ul style="list-style-type: none"> <li>a.) Re-lock the motor</li> <li>b.) Electronic friction adjustment on display, through point anti-squeezing</li> <li>c.) Remove obstacle</li> </ul>  |
| Gate doesn't reach the complete Open / Closed position | <ul style="list-style-type: none"> <li>a.) Wrong setting of the limit switches</li> <li>b.) Error on programming</li> <li>c.) Gate is stopped by an obstacle</li> <li>d.) The fitting geometry is inadequate</li> </ul> | <ul style="list-style-type: none"> <li>a.) Set limit switches</li> <li>b.) Repeat programming</li> <li>c.) Remove obstacle</li> <li>d.) Check fitting geometry following the operator installation manual</li> </ul>                         |
| The gate opens but doesn't close                       | <ul style="list-style-type: none"> <li>a.) The photocell contacts are not closed</li> </ul>   | <ul style="list-style-type: none"> <li>a.) Check LED and jumpers or the signals indicated on the warning lamp</li> </ul>   |
| The gate doesn't close automatically                   | <ul style="list-style-type: none"> <li>a.) Pause time set to high</li> <li>b.) Control unit in semi-autom. logic</li> </ul>   | <ul style="list-style-type: none"> <li>a.) Adjust pause time</li> <li>b.) Adjust the automatic or security logic</li> </ul>  |



# WARNINGS AND WARRANTY

## WARNINGS

The electric installation and the functioning logic choice must agree with the laws in force. In any case you must foresee a 16A and threshold 0.030A differential switch. Keep the power cables (motors, power supply) separate from the command cables (push buttons, photocells and so on). In order to avoid any interference it's preferable to use two separate cables and ducts

## REPLACEMENTS

Any request for spare parts must be sent to:  
**SEA s.r.l. - Zona Ind.le, 64020 S.ATTO - Teramo - Italia**

## USE DESTINATION

The electronic equipment 23024015/16 has been designed to be used exclusively as management equipment for sliding gates automation, swing gates, sectional doors, overhead doors, barriers.

## SAFETY AND ENVIRONMENTAL COMPATIBILITY

Disposal of the packaging materials of products and/or circuits should take place in an approved disposal facility.



### REGULAR PRODUCT DISPOSAL (electric and electronic waste)

(It's applicable in EU countries and in those ones provided with a differential rubbish collection)

The brand that you find on the product or on documentation signals that the product must not be disposed off together with other domestic rubbish at the end of life cycle. In order to avoid any possible environmental or health damage because of the irregular waste disposal, we ask you to separate this product from other forms of rubbish and to recycle it in a responsible way in order to provide the sustainable re-use of material resources. Domestic users are invited to contact the retailer where the product has been purchased or the local office in charge of all the information related to differential collection and recycling of this kind of product.

## STORING

| WAREHOUSING TEMPERATURES |                  |                          |                           |
|--------------------------|------------------|--------------------------|---------------------------|
| T <sub>min</sub>         | T <sub>Max</sub> | Dampness <sub>min</sub>  | Dampness <sub>Max</sub>   |
| - 40°C                   | + 85°C           | 5% <i>Not condensing</i> | 90% <i>Not condensing</i> |

Materials handling must be made with appropriate vehicles..

## REPLACEMENT AND MAINTENANCE

The replacement and/or putting out of service and/or maintenance of the electronic equipment 23024015/16 must be made only and exclusively by authorised and qualified staff.

## WARRANTY LIMITS

The warranty form of the electronic equipment 23024015/16 is valid for 24 months starting from the printed date on the product. The mentioned product will be considered under warranty if it doesn't show any damage caused by an irregular use or by any modification or breaking. The warranty is valid only for the original buyer.

**NOTE:THE MANUFACTURER IS NOT CONSIDERED RESPONSIBLE FOR ANY DAMAGE CAUSED BY IRREGULAR, WRONG OR UNREASONABLE USE.**

---

*SEA reserves the right to make any required modification or change to the products and/or to this manual without any advanced notice obligation.*

---