HOW TO ....

Connect I-GATE to the BULL1524

CP.B1524

J3

M2

BLINK | AUX2 | COM | SWO | SWC | STOP | PHOTC | PHOTO | PED | P.P.

F1

M3

MOT | + 24V - | AUX1 | BAR | SHLD | ANT

24V DC
INPUT

NO COM
RELAY 1

I-GATE